



Part #: ST-CC

Product: SpeedTrends Ceramic Coat Paint Protection

No warranty is made or implied for products sold through SpeedTrends against protection from damage, injury or death. Under consideration for the purchase of these components, the buyer agrees to release, indemnify and hold SpeedTrends harmless for, and assume all risk of any injury or damages that may arise from the use of this product. Ceramic Coat Paint Protection is always recommended to be applied by a competent and knowledgeable installer. User assumes full risk. SpeedTrends is not responsible for errors, typographical or otherwise, in this installation guide.

Please note precautionary statement:

- Keep out of reach of children
- Keep away from heat, sparks, open flames and hot surfaces
- Avoid breathing dust, fumes, gas, mist, vapor and spray
- Do not get on eye, on skin or clothing
- If on skin, then gently wash with soap and warm water
- Do not eat, drink or smoke while using this product
- Wear protective gloves, clothes, eye and face protection
- Wear respiratory protection
- If swallowed, then rinse mouth and do not induce vomiting
- Store in a well ventilated place in a tightly closed container

Hazard statement:

- Flammable liquid and vapor
- May cause respiratory irritation
- Harmful if swallowed
- Harmful if in contact with skin
- Harmful to aquatic life

HMIS Ratings

Ceramic Coat Paint Protection

2 HEALTH

3 FLAMMABILITY

1 REACTIVITY

Application Instructions:

Note: Ceramic coat must be applied to surface in a cool shaded area. DO NOT APPLY IN TEMPERATURE BELOW 50°F

1. Thoroughly clean surface to be applied ceramic coat of dirt, debris and dust.
2. Remove wax and silicone from car with an auto detailing wax and tar remover
3. Shake Ceramic Coat Paint Protection spray bottle well
4. Generously spray a light mist over surface and work in sections about the size of the door
5. Use a microfiber towel to wipe the Ceramic Coat evenly across the applied surface
6. Move to the next area and apply more Ceramic Coat
7. If you see any cloudy areas, then apply more Ceramic Coat and buff with the towel
8. Reuse every 6 to 8 months as maintenance to revitalize the Ceramic Coat.